


Basic Wiring Diagram



Accessories

Accessories	Part No.
USB Cable (A to Mini B), 2 meters	56-1346
Power Cable, 1 meter	56-1348
I/O Cable, 1 meter	56-1352
RS-485 Cable, 1 meter	56-1536-4
Software Installation Disk	55-010
Motor Connector Assembly	56-1453
USB to RS-485 Adapter	UTR4852
Encoder Cable with flying leads, 1 foot	56-1715
Encoder Harness to E4 encoder, 1 meter	56-1639-4
Encoder harness to E5/E6 encoder, 1 meter	56-1621-4